

## ข้อมูลเทคนิค...การปรับตั้งจานแบบ...ไทยแซท

จังหวัด นครนายก      ละติจูด 14.2      ลองจิจูด 101.21



ตำแหน่ง	ดาวเทียม	แนว LNB	มุมก้ม	มุมส่าย
49.0 E	Yamal 202	-	61.2	259.2
57.0 E	NSS12	-	52.9	255.8
64.2 E	Intelsat 906	-	45.5	252.0
66.0 E	Intelsat 17	6:38	43.6	250.8
78.5 E	Thaicom 5/6	7:00	31.1	239.6
68.5 E	Intelsat 20	6:41	41.1	249.1
75.0 E	ABS-2	6:52	34.5	243.5
76.5 E	Apstar 7	6:56	33.0	241.9
83.0 E	Insat 4A	7:13	26.9	233.3
87.5 E	Chinasat12,ST2	7:30	23.0	224.8
91.5 E	Measat 3/3A	7:50	20.1	214.9
93.5 E	Insat 3A/4B	8:02	18.9	208.9
100.5 E	AsiaSat 5	8:54	16.7	182.9
105.5 E	AsiaSat 7	9:34	17.4	163.0
108.2 E	Telkom 1	9:53	18.6	153.4
110.5 E	Chinasat 10	10:07	19.9	146.3
113.0 E	Palapa D	10:20	21.6	139.6
115.5 E	ChinaSat 6B	10:32	23.5	133.9
125.0 E	ChinaSat 6A	11:01	32.1	119.1
132.0 E	Vinasat 1,2	11:15	39.1	112.4
134.0 E	Apstar 6	11:18	41.1	110.8
138.0 E	Telstar 18	11:23	45.2	108.2
166.0 E	Intelsat 19	11:46	74.0	96.6
169.0 E	Intelsat 805	11:48	77.0	95.7
180.0 E	Intelsat 18	11:54	87.8	92.8