

ข้อมูลเทคนิค...การปรับตั้งจานแบบ...ไทยแซท

จังหวัด กระจับปี่ ละติจูด ลองจิจูด

11.81

99.8



ตำแหน่ง	ดาวเทียม	แนว LNB	มุมก้ม	มุมสาย
49.0 E	Yamal 202	-	59.3	260.5
57.0 E	NSS12	-	50.8	257.5
64.2 E	Intelsat 906	-	43.2	254.0
66.0 E	Intelsat 17	6:34	41.3	253.0
78.5 E	Thaicom 5/6	6:55	28.3	242.3
68.5 E	Intelsat 20	6:37	38.7	251.4
75.0 E	ABS-2	6:47	31.9	246.1
76.5 E	Apstar 7	6:50	30.4	244.6
83.0 E	Insat 4A	7:08	24.0	235.9
87.5 E	Chinasat12,ST2	7:26	20.0	226.8
91.5 E	Measat 3/3A	7:49	16.9	215.5
93.5 E	Insat 3A/4B	8:03	15.7	208.3
100.5 E	AsiaSat 5	9:06	13.9	176.6
105.5 E	AsiaSat 7	9:52	15.4	154.0
108.2 E	Telkom 1	10:11	17.0	144.2
110.5 E	Chinasat 10	10:25	18.7	137.3
113.0 E	Palapa D	10:37	20.7	131.1
115.5 E	ChinaSat 6B	10:47	22.9	126.1
125.0 E	ChinaSat 6A	11:12	32.3	113.5
132.0 E	Vinasat 1,2	11:23	39.6	108.0
134.0 E	Apstar 6	11:26	41.7	106.8
138.0 E	Telstar 18	11:30	46.0	104.6
166.0 E	Intelsat 19	11:49	75.2	95.2
169.0 E	Intelsat 805	11:51	78.2	94.4
180.0 E	Intelsat 18	11:55	89.1	92.0